



POS.	CODE	DESCRIPTION	QTY
1	A00121	STOP PIN	1
2	A00122	CIRCLIP	1
3	A00123	GRIP SLIPPER	1
4	A00124	SPRING	1
5	A00125	LOCKING SLEEVE	1
6	A00126	O-RING	1
9	A00129	O-RING	1
10	A00130	STEEL SLEEVE	1
11	A00131	SECOND STRIKER	1
12	A00132	O-RING	1
13	A00133	O-RING	1
14	A00134	WASHER	1
15	A00135	RUBBER RING	1
16	A00136	LOCKING CIRCLE	1
17	A00137	CYLINDER CASE	1
18	A00138	SCREW	6
19	A00139	O-RING	3
20	A00140	CYLINDER	1
21	A00141	O-RING	2
22	A00142	RAM	1
23	A00143	PISTON PIN	1
24	A00144	PISTON	1
25	A00145	O-RING	1
26	A00146	NEEDLE BEARING	1
27	A00147	CONNECTING ROD	1
28	A00148	O-RING	1
29	A00149	SCREW	4
30	A00150	SCREW	12
31	A00151	UPPER COVER	1

POS.	CODE	DESCRIPTION	QTY
32	A00152	AIR GUIDE PLATE	1
33	A00153	FLAT PIN	2
34	A00154	CIRCLIP	1
35	A00155	BIG GEAR	1
36	A00156	BEARING	1
37	A00157	SEAL	1
38	A00158	MIDDLE SHAFT	1
39	A00159	NEEDLE BEARING	2
40	A00160	WASHER	2
41	A00161	FIRST&SECOND GEAR	1
42	A00162	CRANK SHAFT CASE	1
43	A00163	CIRCLIP	1
44	A00164	BEARING	1
45	A00165	CRANK SHAFT	1
46	A00166	O-RING	1
47	A00167	GREASE WINDOW SEAT	1
48	A00168	SCREW	7
49	A00169	FELT COLUMN	1
50	A00170	SEAL	1
51	A00171	INNER GREASE CAP	1
52	A00172	SELF-TAPPING SCREW	9
53	A00173	SEAL WASHER	1
54	A00174	OUTER GREASE CAP	1
55	A00175	BEARING	1
56	A00176	WASHER	1
57	A00177	ROTOR	1
58	A00178	SELF-TAPPING SCREW	2
59	A00179	STATOR	1
60	A00180	MOTOR HOUSING	1

POS.	CODE	DESCRIPTION	QTY
61	A00181	BRUSH HOLDER	2
62	A00182	CARBON BRUSHES SET	1
63	A00183	INSERT PLATE	1
64	A00184	BEARING SLEEVE	1
65	A00185	BEARING	1
66	A00186	BEARING CLAMP	1
67	A00187	AIR GUIDER	1
68	A00188	FAN	1
69	A00189	INDUCTANCE	1
70	A00190	LOWER COVER	1
71	A00191	SCREW	4
72	A00192	CONTROLLER	1
73	A00193	CAPACITANCE	1
74	A00194	WIRING BOARD	1
75	A00195	SELF-TAPPING SCREW	2
76	A00196	SWITCH	1
77	A00197	NEON COVER	1
78	A00198	CORD PRESS PLATE	1
79	A00199	CORD SHEATH	1
80	A00200	SELF-TAPPING SCREW	4
81	A00201	WASHER	7
82	A00202	HANDLE SEAT	1
83	A00203	SPRING	2
84	A00204	UPPER ANTI-VIBRATION	1
85	A00205	LOWER ANTI-VIBRATION	1
86	A00206	HANDLE	1
87	A00207	SELF-TAPPING SCREW	2
88	A00208	HANDLE CAP	1
89	A00209	CORD	1

POS.	CODE	DESCRIPTION	QTY
90	A00210	OIL SLINGER	1
91	A00211	WIRING TERMINAL	1
92	A00212	O-RING	1
93	A00213	SLOT	2
94	A00214	SCREW	2
95	A00215	NUT	2
96	A13498	SPRING	1
97	A00128	GASKET	1
98	A02159	SCREW	3
99	A10706	FELT PLUG	1
101	A00216	BOLT	1
102	A00217	CLAMPING SEAT 1	1
103	A00218	FIXING PIECE	2
104	A00219	CLOLLAR	1
105	A00220	CLAMPING SEAT 2	1
106	A00221	STAR KNOB	1
107	A00222	AUXILIARY LEVER	1
108	A06333	O-RING	1
109	A06340	O-RING	1
SET 1	A13841	AUXILIARY HANDLE	1
SET 2	A13842	CONNECTING ROD	1
SET 3	A13843	CRANKSHAFT CASE	1
SET 4	A13844	MAIN HANDLE	1